



Operating Instruction for Remote:




Match/Clear code between remotes

Match code:



Clear code:



Match/Clear code between remote and receiver

Match code:


Method 1 :

- Step 1. Power on the receiver, and complete step 2 in 10 seconds.
- Step 2. Long press the matching zone key "ON", "OFF" on the remote simultaneously, the lamps flicker several times, the buzzer beep once, match successfully.



Method 2 :

- Step 1. Short press the ID learning button on the receiver, the buzzer beep once.
- Step 2. Long press the matching zone key "ON", "OFF" on the remote simultaneously, the lamps flicker several times, the buzzer beep once, match successfully.



Clear code:

Method 1 :

- Power on and off the receiver continuously for 5 times, If the buzzer long beep and lamps flicker twice, deactivate the matching successfully.



Method 2:

- Long press "ID learning button" on receiver for 5 seconds, If the lamps flicker twice, deactivate the matching successfully.



Wiring Diagram :

